


Auswahltable Standardtypen / Selection Table Standard Types

Kontaktelement / Contact Element

Gelbe Haube / Yellow Cover



Betätigungsvarianten / Activation Device



Keine Sicherheitsvorrichtung /
None safety mechanism



Sicherheitshebel /
Safety lever



Pedalverriegelung /
Pedal lock



1NO+1NC
Sprungschalter /
Snap Action Switch

FSYP11-01

FSYA11-01

FSYM11-01



2NO+2NC
Sprungschalter /
Snap Action Switch

FSYP12-01

FSYA12-01

FSYM12-01



1NO+1NC
Schleichschalter /
Slow Action Switch

FSYP13-01

FSYA13-01

FSYM13-01



2NO+2NC
Schleichschalter /
Slow Action Switch

FSYP14-01

FSYA14-01

FSYM14-01



2NO+2NC
Sprungschalter 2-stufig
Snap Action Switch 2-step

FSYP42-01

FSYA42-01

FSYM42-01



2NO+2NC
Schleichschalter 2-stufig
Slow Action Switch 2-step

FSYP44-01

FSYA44-01

FSYM44-01



1NO+1NC
Sprungschalter /
Snap Action Switch

FSYP21-01

FSYA21-01

FSYM21-01



2NO+2NC
Sprungschalter /
Snap Action Switch

FSYP22-01

FSYA22-01

FSYM22-01



1NO+1NC
Schleichschalter /
Slow Action Switch

FSYP23-01

FSYA23-01

FSYM23-01



2NO+2NC
Schleichschalter /
Slow Action Switch

FSYP24-01

FSYA24-01

FSYM24-01



2NO+2NC
Sprungschalter 2-stufig /
Snap Action Switch 2-step

FSYP52-01

FSYA52-01

FSYM52-01



2NO+2NC
Schleichschalter 2-stufig /
Slow Action Switch 2-step

FSYP54-01

FSYA54-01

FSYM54-01



1NO+1NC
Sprungschalter /
Snap Action Switch

FSYP31-01

FSYA31-01

FSYM31-01



2NO+2NC
Sprungschalter /
Snap Action Switch

FSYP32-01

FSYA32-01

FSYM32-01



1NO+1NC
Schleichschalter /
Slow Action Switch

FSYP33-01

FSYA33-01

FSYM33-01



2NO+2NC
Schleichschalter /
Slow Action Switch

FSYP34-01

FSYA34-01

FSYM34-01